

## Robert Bosch Spark Plug Cross Reference, 1971

Cross-references many vintage spark plug brands  
to the corresponding Bosch spark plug.

*This document was obtained from*

*Jim Solberg's Vintage Snowmobiles*

*[www.bayshorecad.com/Sleds](http://www.bayshorecad.com/Sleds)*

# CROSS REFERENCE

AC	BOSCH	AC	BOSCH	AC	BOSCH
14		85T	MA145T1	C77L	
16		85TS	MA125T7	C78L	
16L		86T	MA95T1	C81	M260T1
17	Z45T4	86TS	MA125T7	C82	M240T1
18	Z45T4	87TS	MA125T7	C82T	MA175T1
18A	M145T5	104	U175T3	C83	M225T1
26		401	W240T3	C83T	MA145T1
40TS	WA200T40	402FF	W225T1	C84T	MA145T1
41	W240T3	403	W175T3	C85	M175T1
41TS	WA200T40	404	W145T3	C85TS	MA125T7
41XL	W240T2	436S		C86	M145T5
41XLS	W230T30	436TS		C87	M95T5
42F	W225T1	436XLS	W300T30	C88	M45T5
42FS	W225T35	438S		C88L	
42FF	W225T1	438TS		CR42N (note #1)	W225T2
42S	W175T6	438XLS	W280T30	CR42T (note #1)	WA200T40
42TS	WA200T40	440S	(use) W240T3	CR43 (note #1)	W175T3
42XL	W225T2	440TS	WA200T40	CR43K (note #1)	W175T3
42XLS	W200T30	440XLS	W260T30	CR43L (note #1 & 2)	W175T1
43	W175T3	441S	(use) W225T3	CR43N (note #1)	W175T2
43FS	W175T35	441TS	WA200T40	CR44N (note #1)	W160T2
43FFS	W175T35	441XLS	W230T30	CR44NS (note #1)	W160T30
43K	W175T3	442	W225T3	CR44XL (note #1)	W175T2
43LS (note #2)	W175T35	442F	W225T1	CR45L (note #1)	W125T4
43N	(use) W175T2	443S	W175T6	CR45XL (note #1)	W145T2
43S	W175T6	443FF	W175T1	CR82 (note #1)	M240T1
43TS	WA125T40	443TS	W125T40	CR83 (note #1)	M225T1
43XL	W175T2	443XLS	W175T30	CR83T (note #1)	MA145T1
43XLS	W175T30	444	W145T3	CR84T (note #1)	MA145T1
44	W145T3	444FF	W145T1	CS41T	
44F	W145T1	444S	W145T6	CS42	WKA225T38
44FF	W145T1	444TS	WA125T40	CS42T	
44FFS	W145T35	444XLS	W160T30	CS45	WKA175T38
44N	(use) W160T2	700Y		CS45T	
44NS	(use) W160T30	701Y		CS49	(use) W45T3
44S	W145T6	800LY		G53	Z45T4
44TS	WA125T40	883TS	MA175T7	G54	
44XL	W160T2	884TS	MA145T7	G56	
44XLO	W160T30	B43	(use) W175T3	G58	
44XLS	W160T30	B44FFS	(use) W145T35	G59	
45	W145T3	B44S	(use) W145T6	G66	
45F	W145T1	B45	(use) W145T3	G69	
45FF	W145T1	B45FFS	(use) W145T35	G81	M280T31
45FFS	W145T35	B49	(use) W45T3	GC46	W145T3
45L	W125T4	B83F	MV175T1	LM46	W145T3
45LS	(use) W125T4	B86	MV175T1	LM46B	(use) W145T3
45N	W125T37	B4021	(use) W225T3	LM49	W45T3
45NS	(use) W145T30	B4031	(use) W145T3	M8	U145T3
45S	W145T6	C41N	(use) W240T2	M40	W240T3
45TS	WA125T40	C42-1	W225T3	M40FF	W260T1
45XL	W145T2	C42N	(use) W225T2	M40FFG	W270T16
45XLS	W145T30	C43	W175T3	M41FF	W240T1
46	W95T3	C43L (note #2)	W175T1	M41FFG	W240T16
46FF	W95T1	C43N	(use) W175T2	M41G	
46FFS	(use) W95T1	C44	W145T3	M41K	W240T3
46N	W125T37	C44N	(use) W160T2	M42FF	W225T1
46S	W95T6	C44NS	(use) W160T30	M42G	
46TS	WA125T40	C44S	W175T6	M42K	W225T3
46XL	W125T2	C44XL	W175T2	M43FF	W145T1
46XLS	(use) W125T2	C45	W145T3	M44B	(use) W145T3
47FF	W45T1	C45L	W125T4	M44C	W145T3
47L (note #2)	W95T1	C45NS	(use) W145T30	M44L	W125T4
47XL	W95T2	C45W (note #2)	WK175T1	M45	W145T3
48	W45T3	C46	W95T3	M45FF	W145T1
78S	Z45T4	C47	W95T3	M47	W45T3
83TS	MA145T7	C47W (note #2)	WK145T1	M81	M280T31
84T	MA145T1	C49	W45T3	M84	M225T1
84TS	MA145T7	C73		MB42K	(use) W225T3
85	M175T1	C75		MC41F	W240T1
		C77		MC42	W225T3

Note #1. (If resistor is necessary, use spark plug resistor connector # 0-356-150-007 (90 degree—elbow type) or 0-356-100-021 (180 degree—straight type).

Note #2. An extra gasket must be used along with the regular gasket—to make this interchange.  
 14 mm Gasket # 2-916-709-010      18 mm Gasket # 2-916-709-011

Note #3. Check piston clearance before using extended tip spark plug to replace regular electrode type.

**Important! Always check electrode gap setting. Since most Bosch Spark Plugs are applicable to many different vehicles, it may be necessary to re-set the electrode gap.**

# CROSS REFERENCE

This document was obtained from  
*Jim Solberg's Vintage Snowmobiles*  
[www.bayshorecad.com/Sleds](http://www.bayshorecad.com/Sleds)

AC	BOSCH	AC	BOSCH	Autolite	BOSCH
MC42F	W225T1	SR47XL (shielded)		A603	
MC44	W145T3	SR83T (shielded)		A901	W240T3
MC102F	U260T1	SR84E (shielded)		A903	
MC104F	U175T1	SR86E (shielded)		AE1W	W240T1
MC121F	X300T1	TC42	W225T3	AE2	W240T1
MC122F	X260T1	TC42L (note #2)	W175T1	AE2W	W225T1
MC124F	X175T1	TC45	W145T3	AE2X	W240T1
MC124FS	(use) X175T1	TC45L	W125T4	AE3	W225T1
MR42K (note #1)	W225T3	TC81	M260T1	AE3X	W225T1
MR44C (note #1)	W145T3	TC82	M240T1	AE4	W175T1
MR45 (note #1)	W145T3	TC83	M225T1	AE4M	W175T1
R40TS		TC85	M175T1	AE4W	W175T1
R41TS	WA200T40	TC86	M145T5	AE4X	W175T1
R42S (note #1)	W175T6	TC88L		AE6	W145T1
R42T (note #1 & 3)	WA200T40	V40		AE22	W225T35
R42TS (note #1)	WA200T40	V40FF	WET 1	AE22M	W225T1
R42XLS (note #1)	W200T30	V40FFS	(use) WET 1	AE23	W240T16
R43 (note #1)	W175T3	V40FFK	WET 1	AE32	W175T35
R43T (note #1 & 3)	WA125T40	V40FFM	WET 1	AE42	W175T35
R43L (note #1 & 2)	W175T1	V40K		AE52	W145T35
R43N (note #1)	W175T2	V40N		AE62	W145T35
R43S (note #1)	W175T6	V40NK		AE82	W145T35
R43TS (note #1)	WA125T40	V400S		AE203	W370T16
R43XL (note #1)	W175T2	WR41N (shielded)		AE403	W340T16
R44 (note #1)	W145T3	WR42 (shielded)		AE603	W310T16
R44T (note #1 & 3)	WA125T40	WR43 (shielded)		AE901	W260T1
R44FF (note #1)	W145T1	WR43L (shielded)		AE901W	W260T1
R44N (note #1)	W160T2	WR43LR (shielded)		AE901X	W260T1
R44S (note #1)	W145T6	WR44 (Shielded)		AE903	W270T16
R44TS (note #1)	WA125T40	WR44LS (shielded)		AEKO	WET 1
R44NS (note #1)	W160T30	WR44T (shielded)		AER3S (shielded)	
R44XL (note #1)	W160T2	WR46 (shielded)		AER4 (note #1)	W175T1
R44XLS (note #1)	W160T30	WR47 (shielded)		AER4S (shielded)	
R45 (note #1)	W145T3	WR84 (shielded)		AER6 (note #1)	W145T1
R45N (note #1)	W125T37	WR86 (shielded)		AF1 (note #3)	WA200T40
R45NS (note #1)	(use) W125T37	WR87 (shielded)		AF2 (note #3)	WA200T40
R45S (note #1)	W145T6	WR104 (shielded)		AF3 (note #3)	WA125T40
R45T (note #1 & 3)	WA125T40			AF12	WA200T40
R45TS (note #1)	WA125T40			AF22	WA200T40
R45XL (note #1)	W145T2			AF32	WA125T40
R45XLS (note #1)	W145T30			AF42	WA125T40
R46 (note #1)	W95T3			AF52	WA125T40
R46FF (note #1)	W95T1			AF103	
R46N (note #1)	W125T37			AF303	
R46S (note #1)	W95T6			AF501	
R46T (note #1 & 3)	WA125T40			AF503	
R46TS (note #1)	WA125T40			AF701	
R46XL (note #1)	W125T2			AF901	
R46XLS (note #1)	W125T2			AG1W	W240T2
R47S (note #1)	W75T6			AG2	W225T2
R83TS (note #1)	MA145T7			AG2M	W225T2
R84TS (note #1)	MA145T7			AG2X	W225T2
R85T (note #1)	MA145T1			AG3	W175T2
R85TS (note #1)	MA125T7			AG3M	W175T2
R86T (note #1)	MA95T1			AG3X	W175T2
R800 (note #1)	M175T1			AG4	W160T2
R800TY (note #1)	MA175T1			AG4M	W160T2
S85TS (shielded)				AG5	W145T2
SN46	W145T3			AG5M	W145T2
SN81FG	M270T16			AG7	W125T2
SN82F	M240T1			AG9	W95T2
SN83F	M225T1			AG12	W230T30
SN85F	M175T1			AG22	W200T30
SR42-3E (shielded)				AG-22A	W200T30
SR43LE (shielded)				AG23	W240T17
SR44E (shielded)				AG32	W175T30
SR45LE (shielded)				AG42	W160T30
SR46E (shielded)				AG52	W145T30
SR47E (shielded)				AG82	W145T30
SR47LE (shielded)				AG203	W370T17

Note #1. (If resistor is necessary, use spark plug resistor connector # 0-356-150-007 (90 degree—elbow type) or 0-356-100-021 (180 degree—straight type).

Note #2. An extra gasket must be used along with the regular gasket—to make this interchange.  
 14 mm Gasket # 2-916-709-010      18 mm Gasket # 2-916-709-011

Note #3. Check piston clearance before using extended tip spark plug to replace regular electrode type.

**Important! Always check electrode gap setting. Since most Bosch Spark Plugs are applicable to many different vehicles, it may be necessary to re-set the electrode gap.**

# CROSS REFERENCE

Autolite	BOSCH	Autolite	BOSCH	Autolite	BOSCH
AG403	W340T17	AT10	W45T3	BTF42	MA145T7
AG501	W260T2	AT42	W145T6	BZ8	MV175T1
AG603	W310T17	AT42M	(use) W145T3	F11	
AG701	W240T2	ATL3 (note #2)	W175T1	HE1	X300T1
AG901	W225T2	ATL4 (note #2)	W145T1	HE2	X260T1
AG902	W260T30	ATL8	W125T4	HE3	X175T1
AG903	W270T17	AU7PM	W145T3	P6	U145T3
AGKO		AZ2	(use) W175T3	PE3	U260T1
AGR3S (shielded)		AZ3	(use) W175T3	TR8S (shielded)	
AGR4M (note #1)	W160T2	AZ9	(use) W95T3	TT4	
AGR4S (shielded)		B2W	M240T1	TT8	Z45T4
AGR5M (note #1)	W145T2	B3W	M225T1	TT10	Z45T4
AGR8S (shielded)		B3X	M225T1	TT15	(use) Z45T4
AGR21 (note #1)	W225T2	B4S (shielded)			
AGR22	W200T30	B4X	M175T1		
AGR31 (note #1)	W175T2	B6X	M175T1		
AGR32 (note #1)	W175T3D	B8S (shielded)			
AGR41 (note #1)	W160T2	B8X	M145T5		
AGR42 (note #1)	W160T30	B82	(use) M145T5		
AGR51 (note #1)	W145T2	B203	M370T16		
AGR52 (note #1)	W145T30	B403	M340T16		
AGR82 (note #1)	W145T30	B601W	M260T1		
AGZ7	(use) W125T2	B603	M310T16		
AKO		B903	M270T16		
AL5	W125T4	BF6S (shielded)			
AL5X	W125T4	BF7	MA95T1		
AL7	W125T4	BF12	MA175T7		
AL7W	W125T4	BF22	MA175T7		
AL7X	W125T4	BF32	MA145T7		
AL7Y	W125T4	BF32M	MA145T7		
AL9	W125T4	BF42	MA145T7		
AL9Y	W125T4	BF42M	MA145T7		
AL11 (note #2)	(use) W95T1	BF82	MA125T7		
AL11Y (note #2)	(use) W95T1	BF92	MA125T7		
AL52 (note #2)	(use) W175T35	BF203			
AL82 (note #2)	(use) W145T35	BF403			
AR2S (shielded)		BF601	MA225T1		
AR4S (shielded)		BF603			
AR4SX (shielded)		BF703			
AR5M (note #1)	W145T3	BR4S (shielded)			
AR5S (shielded)		BR5S (shielded)			
AR6S (shielded)		BR7S (shielded)			
AR8S (shielded)		BR8 (note #1)	M145T5		
AR9S (shielded)		BR8S (shielded)			
AR10 (note #1)	W45T3	BR9S (shielded)			
AR10S (shielded)		BR10S (shielded)			
AR21X	W175T3	BR15S (shielded)			
AR31 (note #1)	W175T3	BRF6 (note #1)	MA95T1		
AR32 (note #1)	W175T6	BRF6S (shielded)			
AR41 (note #1)	W145T3	BRF31 (note #1)	MA145T1		
AR42 (note #1)	W145T6	BRF32 (note #1)	MA145T7		
AR51 (note #1)	W145T3	BRF42 (note #1)	MA145T7		
AR52 (note #1)	W145T6	BRF82 (note #1)	MA125T7		
AR80 (note #1)	W95T3	BT2	M240T1		
AR82 (note #1)	W95T6	BT3	M225T1		
ARF32 (note #1)	WA125T40	BT4	M175T1		
ARF42 (note #1)	WA125T40	BT4M	M175T1		
ARF52 (note #1)	WA125T40	BT6	M145T5		
ARL4S (shielded)		BT6M	M145T5		
ARL6S (shielded)		BT6Y	M145T5		
ARL8 (note #1)	W125T4	BT8	M145T5		
ARL8S (shielded)		BT8Y	M145T5		
AT1	W225T3	BT9	M95T5		
AT2	W175T3	BT10	M95T5		
AT3	W175T3	BT15	M45T5		
AT3M	W175T3	BTF1	MA175T1		
AT4	W145T3	BTF3	MA145T1		
AT4M	W145T3	BTF3M	MA145T1		
AT6	W145T3	BTF6	MA95T1		
AT8	W95T3	BTF31	MA145T1		

BERU	BOSCH
95/14	W95T1
95/14/3	W95T2
95/14/5A	W95T6
125/14/6	W125T4
125/14/3	W125T2
145/14	W145T1
145/14/3	W145T2
145/14/5	W145T3
145/14/5A	W145T6
160/14/3	W160T2
175/14	W175T1
175/14UK4	WK175T1
D175/14	W175T7
175/14A	W175T35
175/14/5	W175T3
175/14/5A	W175T6
175/14/5AM	WKA175T6
175/14/3	W175T2
175/14/3A	W175T30
D175/14/3	W175T2
190/14S	W190M11S
D200/14/3	W200T27
200/14/3A	W200T30
200/14A	W200T35
D215/14/3P	W215P21
D215/14/3S	WG215T28
D215/14/3	W215T28
225/14	W225T1
225/14A	W225T35
225/14UK4	WK225T1
D225/14	W225T7
225/14/3	W225T2
225/14/3S	W225T2S
D225/14/3	W225T2
225/14/5	W225T3
225/14/5AM	WKA225T6
230/14/3A	W230T30
D235/14/3P	W235P21
D235/14/3S	WG235T28
240/14	W240T1
240/14S	W240P11S
240/14/3	W240T2
240/14/3S	W240T2S
D240/14/3	W240T2
D250/14/3P	W250P21
D250/14/3S	WG250T28
260/14	W260T1
260/14S	W270T16
260/14/3	W260T2
D260/14/3	W260T2
260/14/3S	W260T2

Note #1. (If resistor is necessary, use spark plug resistor connector # 0-356-150-007 (90 degree—elbow type) or 0-356-100-021 (180 degree—straight type).

Note #2. An extra gasket must be used along with the regular gasket—to make this interchange.  
 14 mm Gasket # 2-916-709-010      18 mm Gasket # 2-916-709-011

Note #3. Check piston clearance before using extended tip spark plug to replace regular electrode type.

Important! Always check electrode gap setting. Since most Bosch Spark Plugs are applicable to many different vehicles, it may be necessary to re-set the electrode gap.

# CROSS REFERENCE

BERU	BOSCH	CHAMPION	BOSCH	CHAMPION	BOSCH
280/14S	W280T13S	D-14	M145T5	HO-8A	(use) W145T3
280/14/3S	W280T20S	D-14N	M145T5	HW-80N (shielded)	
310/14S	W310T16	D-15Y	M145T5	HW-83F (shielded)	
310/14/3S	W310T17	D-16	M145T5	J-4	W225T3
340/14/3S	W340T17	D-16J	M145T5	J-5	W225T3
400/14/3S	W400T17	D18Y	M95T5	J-6	W175T3
45/18	M45T5	D-21	M95T5	J-7	W145T3
45/18K	MA125T7	D-23		J-8	W145T3
95/18	M95T1	D-89D	MG240T1	J-10Y	W175T6
145/18	M145T5	DJ-6J		J-11	W95T3
145/18K	MA145T1	E-52R		J-11Y	W175T6
175/18	M175T1	E-54R		J-12Y	W145T6
225/18	M225T1	E-55		J-13Y	W145T6
225/18S	M225P11S	E-56R		J-14Y	W145T6
240/18	M240T1	E-57		J-87B	(use) W175T3
260/18	M260T1	E-57R		J-2J	W240T3
280/18S	M280T31	E-58R		J-4J	W225T3
200/10	U260T1	E-59R		J-6J	W175T3
225/10	U260T1	E-60		J-7J	W145T3
240/10	U260T1	E-805 (shielded)		J-8J	W145T3
310/18S	M310T31S	EC-10 (shielded)		J-11J	W95T3
340/18S	M340T31S	EC-85N (shielded)		J-12J	W45T3
		ED-9 (shielded)		J-14J	W45T3
		ED-14 (shielded)		J-17LM	W145T3
		ED-16 (shielded)		J-19V	
		ED-89D (shielded)		J-54R	
		EF-10 (shielded)		J-57R	
		EF-14Y (shielded)		J-60P	
		EH-8 (shielded)		J-60R	
		EHO-8 (shielded)		J-61Y	
		EH-10 (shielded)		J-62R	
		EH-11 (shielded)		J-63Y	
		EJ-6 (shielded)		J-64P	
		EJ-6J (shielded)		J-79	W240T3
		EJ-8 (shielded)		J-83Y	
		EJ-8J (shielded)		J-86Y	
		EJ-11 (shielded)		K-2G	MG300T31
		EJ-12 (shielded)		K-3G	MG280T31
		EK-97F (shielded)		K-5G	MG260T1
		EK-98F (shielded)		K-7	M260T1
		F-10	MA145T1	K-8	M240T1
		F-54R		K-8G	MG240T1
		F-57R		K-9	M225T1
		F-60R		K-12G	MG225T1
		F-60Y		K-13	M175T1
		F-62R		K-15J	M145T5
		F-62Y		K-54R	M370T16
		F-79Y		K-57R	M340T16
		F-81Y		K-59T	M310T16
		F-82	MA175T1	K-60R	M270T16
		F-83Y	MA175T7	K-80R	
		G-54R		K-83R	
		G-56R		K-97F	M240T1
		G-59R		K-98F	M225T1
		G-61		K-185	M260T1
		G-63		L-2G	W280T13S
		H-4 (note #2)	W175T1	L-3G	W260S11S
		H-8 (note #2)	W145T1	L-4J	W225T1
		H-8J (note #2)	W145T1	L-5	W225T1
		H-10	W125T4	L-6G	W240S11S
		H-10J	W125T4	L-7	W175T1
		H-11	W125T4	L-7J	W175T1
		H-11J	W125T4	L-8	W95T1
		H-12 (note #2)	W95T1	L-9J	W145T1
		H-12J	W125T4	L-10	W145T1
		H-14Y (note #2)	W175T35	L-14	W95T1
		H-18Y (note #2)	W145T35	L-19V	WET 1
		HB-80N (shielded)		L-20V	WET 1
		HC-95F (shielded)		L-54R	W340T16
		HO-3	(use) W225T3	L-57R	W310T16

Note #1. (If resistor is necessary, use spark plug resistor connector # 0-356-150-007 (90 degree—elbow type) or 0-356-100-021 (180 degree—straight type).

Note #2. An extra gasket must be used along with the regular gasket—to make this interchange.  
 14 mm Gasket # 2-916-709-010      18 mm Gasket # 2-916-709-011

Note #3. Check piston clearance before using extended tip spark plug to replace regular electrode type.

**Important! Always check electrode gap setting. Since most Bosch Spark Plugs are applicable to many different vehicles, it may be necessary to re-set the electrode gap.**

# CROSS REFERENCE

CHAMPION	BOSCH	CHAMPION	BOSCH	CHAMPION	BOSCH
L-60R	W270T16	REL-88B (shielded)		W-95D	
L-61Y	W240T1	REM-84P (shielded)		XD-6 (note #1)	M240T1
L-62R	W240T16	REW-82P (shielded)		XD-9 (note #1)	M225T1
L-64Y	W225T35	RF-80N (note #1)	MA175T1	XD-14 (note #1)	M145T5
L-66Y	W200T35	RHB-81N (shielded)		XD-16 (note #1)	M145T5
L-77V	WET 1	RJ-6 (note #1)	W175T3	XD-16J (note #1)	M145T5
L-78	W260T1	RJ-8 (note #1)	W145T3	XEC-89D (shielded)	
L-81	W240T1	RJ-10Y (note #1)	W175T6	XED-14 (shielded)	
L-82R	W370T16	RJ-12Y (note #1)	W145T6	XED-16 (shielded)	
L-82Y	W225T35	RJ-13Y (note #1)	W145T6	XED-21 (shielded)	
L-84R	W340T16	RJ-81B (note #1)	W175T3	XED-89D (shielded)	
L-85	W225T1	RJ-88P (note #1 & 2)	W200P1	XEF-14 (shielded)	
L-86	W175T1	RL-12Y (note #1)	W175T35	XEF-14Y (shielded)	
L-87R	W310T16	RL-15B (note #1)	W225T1	XEH-8 (shielded)	
L-87Y	W200T35	RL-85P (note #1)	W200P1	XEH-10 (shielded)	
L-88	W145T1	RM-77N (note #1)	MG260T1	XEH-11 (shielded)	
L-90	W95T1	RM-78P (note #1)	MG240T1	XEJ-6 (shielded)	
L-92Y	W175T35	RM-79F (note #1)	MG225T1	XEJ-7 (shielded)	
L-95Y	W145T35	RMJ-3 (shielded)		XEJ-8 (shielded)	
M-82N	M175T1	RMN-3 (shielded)		XEJ-11 (shielded)	
N-2G	W280T20S	RN-6 (note #1)	W160T2	XEJ-12 (shielded)	
N-3	W240T2	RN-8 (note #1)	W125T2	XEK-9 (shielded)	
N-3G	W260T2	RN-10Y	W175T30	XEK-23 (shielded)	
N-4	W225T2	RN-12Y	W160T30	XEN-14 (shielded)	
N-4G	W240T2	RN-77B	WG235T28	XEN-18 (shielded)	
N-5	W175T2	RS-79N		XF-9Y (note #1)	MA145T7
N-6	W160T2	RW-80N		XF-10 (note #1)	MA145T1
N-6Y	W230T30	RW-82P		XF-11Y (note #1)	MA125T7
N-7Y	W230T30	RW-83F		XF-14Y (note #1)	MA125T7
N-8	W145T2	S-79N		XH-8 (note #1 & 2)	W145T1
N-8Y	W200T30	TJ-6J	WKA175T38	XH-10 (note #1)	W125T4
N-9Y	W200T30	TJ-8J	(use) W145T3	XH-11 (note #1)	W125T4
N-10Y	W175T30	UBL-13Y	WA125T40	XH-12 (note #1 & 2)	W95T1
N-11Y	W175T30	UCJ-7G	(use) WKA225T38	XH-14Y (note #1 & 2)	W175T35
N-12Y	W160T30	UD-16	(use) M145T5	XH-18Y (note #1 & 2)	W145T35
N-14Y	W145T30	UF-9Y	(use) MA145T7	XJ-4J (note #1)	W225T3
N-16Y	W145T30	UF-11Y	(use) MA125T7	XJ-6 (note #1)	W175T3
N-19V		UF-14Y	(use) MA125T7	XJ-6J (note #1)	W175T3
N-21	W95T2	UJ-6	(use) W175T3	XJ-7 (note #1)	W145T3
N-52R	W370T17	UJ-7G	(use) W225T3	XJ-8 (note #1)	W145T3
N-54R	W340T17	UJ-8	(use) W145T3	XJ-8J (note #1)	W145T3
N-57	W280T20S	UJ-10Y	(use) W175T6	XJ-10Y (note #1)	W175T6
N-57R	W310T17	UJ-11G	(use) W175T3	XJ-11 (note #1)	W95T3
N-60	W260T2	UJ-12	(use) W45T3	XJ-11Y (note #1)	W175T6
N-60R	W270T17	UJ-12Y	(use) W145T6	XJ-12 (note #1)	W45T3
N-60Y	W300T30	UJ-17V		XJ-13Y (note #1)	W145T6
N-62R	W240T17	UJ-18Y	(use) W95T6	XJ-14Y (note #1)	W145T6
N-63Y	W280T30	UJ-60P		XJ-18Y (note #1)	W95T6
N-64Y	W260T30	UJ-64P		XJ-20Y (note #1)	W75T6
N-65Y	W230T30	UK-7	MV225T1	XJA	W145T3
N-66Y	W230T30	UK-10	MV175T1	XL-10 (note #1)	W145T1
N-77R	W370T17	UK-16V		XL-12Y (note #1)	W175T35
N-78B	W260T2	UK-180	MV225T1	XL-85 (note #1)	W225T1
N-80B	W240T2	UL-12Y	(use) W175T35	XL-87Y (note #1)	W200T35
N-81R	W240T2	UL-15Y	(use) W145T35	XMJ-14 (shielded)	
N-83R		UL-18V	(use) WET 1	XN-4 (note #1)	W225T2
N-84	W175T2	UL-19V	(use) WET 1	XN-5 (note #1)	W175T2
N-88	W145T2	UL-77V	(use) WET 1	XN-6 (note #1)	W160T2
P-6	X300T1	UL-82Y	(use) W225T35	XN-8 (note #1)	W145T2
P-7	X260T1	UN-12Y	(use) W160T30	XN-9Y (note #1)	W200T30
P-7Y	X175T1	UTJ-11P	(use) WKA175T38	XN-12Y (note #1)	W160T30
R-6	X240T17	UY-6	(use) U145T3	XN-14Y (note #1)	W145T30
R-52R	X310T17	W-10		XN-16Y (note #1)	W145T30
R-54R	X290T17	W-14	Z45T4	Z-6	U260T1
R-56R	X270T17	W-18	Z45T4	Z-8	U260T1
R-59R	X240T17	W-20	Z45T4	Z-10	U175T1
R-61	X240T17	W-77N			
R-63	X240T17	W-80N			
RB-76N		W-85N	Z45T4		
RBL-13Y (note #1)	WA125T40	W-89D			

Note #1. (If resistor is necessary, use spark plug resistor connector # 0<sub>2</sub>356-150-007 (90 degree—elbow type) or 0-356-100-021 (180 degree—straight type).

Note #2. An extra gasket must be used along with the regular gasket—to make this interchange.  
 14 mm Gasket # 2-916-709-010      18 mm Gasket # 2-916-709-011

Note #3. Check piston clearance before using extended tip spark plug to replace regular electrode type.

**Important! Always check electrode gap setting. Since most Bosch Spark Plugs are applicable to many different vehicles, it may be necessary to re-set the electrode gap.**

# CROSS REFERENCE

HARLEY-DAVIDSON	BOSCH
3	W125T4
3-4	W145T6
4 (note #2)	W175T1
5	W225T3
7	W225T2

HITACHI	BOSCH
M22	X300T1
M44	W225T1
M45	W175T1
M46	W145T1

KLG	BOSCH
DF50	W95T1
DF75	W145T1
DF80	W225T1
DFE75	W160T2
F20	W145T1
F50	W145T1
F55P	W145T35
F65P	W200T35
F70	W145T1
F75	W175T1
F80	W175T1
F85P	W225T35
F100	W225T1
FA50	W125T4
FA70 (note #2)	W145T1
FE20	W95T2
FE45P	W160T30
FE50	W125T2
FE55P	W200T30
FE65P	W200T30
FE70	W175T2
FE75	W225T2
FE80	W160T2
FE100	W240T2
FE125P	W230T30
FS20	(use) W95T3
FS30	W95T3
FS35P	(use) W75T6
FS45P	W95T6
FS50	W145T3
FS50H	W145T3
FS55P	(use) W175T6
FS70	W145T3
FS75	W175T3
FS75H	W175T3
FS100	
FS100H	W240T3
M30	M95T5
M50	M145T5
M60	MV175T1
M80	M225T1
MT45P	(use) MA125T7
MT55P	(use) MA125T7
MT65P	(use) MA145T7
T90	U260T1
TENL30	U175T1
TENL70	U175T1
TENL100	U260T1
TMT50	MA145T1
TW100	X260T1
TW220	X300T1

LODGE	BOSCH
2H	W145T1
2HA	W145T3
2HAN	W225T3
2HL	W225T2
2HL10	U260T1
2HLN	W240T2
2HLNY	W230T30
2HN	W225T1
2HNY	W225T35
3HAN	W240T3
3HLN	W240T2
3HN	W225T1
BAN	(use) W95T3
BANY	W95T6
BBL	M95T5
BL14	W95T2
BLN	W95T2
BLNY	W160T30
BN	W145T1
BNY	(use) W145T35
BTNY	(use) MA125T7
C14	W145T1
CAN	W145T3
CANY	W175T6
CC14	W95T1
CL10	U175T1
CL14	W125T2
CLN	W125T2
CLN14P	W125T2
CLNH	W125T2
CLNY	(use) W175T30
CN	W145T1
CNY	(use) W145T35
CSN	W125T4
CTNY	(use) MA125T7
CTN8	MA145T1
CV	M145T5
H14	W175T1
HAN	W175T3
HBLN	W160T2
HF2HL	W225T2
HH14	W225T35
HL10	U175T1
HL14	W175T2
HLN	W225T2
HLNP	W175T2
HLNY	W200T30
HN	W175T1
HNY	W200T35
HTNY	(use) MA145T7
HV	MV175T1

NGK	BOSCH
A-4F	MA95T1
A-6	M175T1
A-6F	MA145T1
A-6FS	MA145T1
A-7	M225T1
A-7F	MA175T1
A7FS	MA175T1
A-8	M240T1
A-8F	MA225T1
A-9F	
A-9N	M310T16
A-10N	M340T16
AB-2	M45T5
AB-6	M95T5

NGK	BOSCH
AB-7	M145T5
AB-83K	M270T16
AB-93K	M340T16
AP-4F	MA125T7
AP-6F	MA145T7
AP-6FS	MA145T7
B-2	W45T3
B-4	W95T3
B-4E	W125T2
B-4H	W145T1
B-4L	W125T4
B5ES	W145T2
B-6	W145T3
B-6E	W160T2
B6ES	W160T2
B-6H	W175T1
B-6HS	W175T1
B-6L	W125T4
B-6S	W145T3
B-7	W175T3
B-7C	W175T3
B-7E	W175T2
B-7EC	W175T2
B-7EJ	W175T2
B-7EJ6	W175T2
B-7ES	W175T2
B-7H	W225T1
B-7HC	W175T1
B-7HS	W225T1
B-7HZ	W225T1
B-7S	W175T3
B-8	W225T3
B-8E	W225T2
B-8EJ6	W225T2
B-8EN	W240T17
B-8ES	W225T2
B-8H	W240T1
B-8HC	W240T1
B-8HN	W240T16
B-8HS	W240T1
B-8HZ	W240T1
B-8N (note #2)	W240T16
B-8S	W225T3
B-9	W240T3
B-9E	W240T2
B-9EJ	W240T2
B-9EN	W270T17
B-9ES	W240T2
B-9H	W260T1
B-9HC	W260T1
B-9HN	W270T16
B-9N (note #2)	W270T16
B-9S	W240T3
B-10	
B-10E	W260T2
B-10EN	W340T17
B-10ES	W260T2
B-10H	W280T13S
B-10HN	W310T16
B-10N (note #2)	W310T16
B-11N (note #2)	W340T16
B-11EN	W400T17
B-11HN	W340T16
B12N (note #2)	W370T16
B-12EN	W440T17
B-12HN	W370T16
B-77C	W225T3
B-77EC	W225T2
B-77HC	W225T1
B-85EN	W270T17

Note #1. (If resistor is necessary, use spark plug resistor connector # 0-356-150-007 (90 degree—elbow type) or 0-356-100-021 (180 degree—straight type).

Note #2. An extra gasket must be used along with the regular gasket—to make this interchange.  
 14 mm Gasket # 2-916-709-010      18 mm Gasket # 2-916-709-011

Note #3. Check piston clearance before using extended tip spark plug to replace regular electrode type.

Important! Always check electrode gap setting. Since most Bosch Spark Plugs are applicable to many different vehicles, it may be necessary to re-set the electrode gap.

# CROSS REFERENCE

NGK	BOSCH
B-95EN	W310T17
B-105EN	W370T17
BL-6 (note #2)	WK145T1
BL-6H	WK145T1
BM-6A	WKA175T38
BM-6F	
BM-7A	WKA225T38
BP-2E	W145T30
BP-2H	W145T35
BP-4	W145T6
BP-4E	W160T30
BP-4H	W175T35
BP-5ES	W175T30
BP-6	W175T6
BP-6E	W200T30
BP6ES	W200T30
BP-6FS	WA125T40
BP-6H	W200T35
BP-6HS	W200T35
BP-6S	W175T6
BPR-6S (note #1)	W175T6
BPR-6FS (note #1)	WA125T40
BPR6ES (note #1)	W200T30
BP-7E	W230T30
BP7ES	W230T30
BP-7FS	WA200T40
BP-7H	W225T35
BP-7HS	W225T35
BPM-7	WKA225T36
BPM-7A	WKA175T36
BR-6S (note #1)	W145T3
BR7ES (note #1)	W175T2
BP-8ES	W260T30
BUHX	WET 1
C-4H	U175T1
C-6H	U175T1
C-6HB	U175T1
C-6HS	U175T1
C-6M	U175T1
C-7HS	U260T1
C-7HW	U260T1
C-7HWB	U260T1
C-9H	U260T1
C-10H	
C-10HA	
C-12H	
C-13H	
C-14H	
C-50C	U175T3
D-4E	X240T17
D-4H	X175T1
D-6H	X260T1
D-6HS	X260T1
D-6HW	X260T1
D-6E	X240T17
D-7ES	X270T17
D-8E	X290T17
D-8ES	X290T17
D-8H	X300T1
D-8HS	X300T1
D-9HS	X300T1
D-10E	X300T2
D-10H	X320T1
D-10HS	X320T1
D-12E	X270T17
D-12H	
D-13E	X290T17
D-13H	
D-14E	X310T17
D-14H	

NGK	BOSCH
F-23	Z45T4
G-2Z	
SA-104	

NIPPONDENSO	BOSCH
M14	M145T5
M17	M175T1
M22	M225T1
MA9P	MA125T7
MA14P	MA145T7
MA17P	MA175T7
U17F	U175T1
U20FB	U175T1
U20FS	U175T1
U21FB	U260T1
U22FB	U260T1
U22FS	U260T1
U24FB	U260T1
W9	W95T3
W9EP	(use) W95T2
W9FP	(use) W95T1
W9P	W95T6
W14	W145T3
W14E	W145T2
W14F	W145T1
W14EP	W145T30
W14FP	W145T35
W14P	W145T6
W17	W175T3
W17E	W175T2
W17F	W175T1
W17EW	W175T2
W17FP	W175T35
W17P	W175T6
W17ES	W175T2
W20EP	W200T30
W22	W225T3
W22E	W225T2
W22EH2	W225T2
W22EP	W230T30
W22ES	W225T2
W22F	W225T1
W24	W240T3
W24E	W240T2
W24F	W240T1
W24ES	W240T2
W25EH2	W260T2
X17F	X175T1
X20E	X240T17
X20FS	X260T1
X22ES	X270T17
X24ES	X290T17
X24FS	X300T1
X28FS	X320T1

PRESTOLITE	BOSCH
10-6	U145T3
14-01 (note #2)	(use) WET 1
14-2X	W225T3
14-3	W225T3
14-3X	W175T3
14-4	W175T3
14-5	W145T3
14-5X	W145T3
14-7	W95T3
14-7N	WKA225T38

PRESTOLITE	BOSCH
14-7X	W145T3
14-9	W95T3
14-9X	W95T3
14-11	W45T3
14-11N	WKA175T38
14-11X	W45T3
14-32	W175T6
14-42	W145T6
14-52	W95T6
14-82	W75T6
14-E2	W175T1
14-E4	W145T1
14-E6	W95T1
14-E22	W225T35
14-E32	W175T35
14-E42	W175T35
14-E52	W145T35
14-E62	W145T35
14-E82	W95T1
14-ER4 (note #1)	W145T1
14-ER6 (note #1)	W95T1
14-F32	WA200T40
14-F42	WA125T40
14-F52	WA125T40
14EO1	WET 1
14-G2	W225T2
14-G3	W175T2
14-G4	W160T2
14-G5	W145T2
14-G7	W125T2
14-GO1	
14-G22	W200T30
14-G32	W175T30
14-G42	W160T30
14-G52	W145T30
14-GR3 (note #1)	W175T2
14-GR4	W160T2
14-GR5	W145T2
14-GR7 (note #1)	W125T2
14-GR32 (note #1)	W175T3
14-GR42 (note #1)	W160T30
14-GR52	W145T30
14-L4 (note #2)	W145T1
14-L7	W125T4
14-L7X	W125T4
14-L9 (note #2)	W95T1
14-R3 (note #1)	W225T3
14-R4 (note #1)	W175T3
14-R5 (note #1)	W145T3
14-R8 (note #1)	W95T3
14-R32 (note #1)	W175T6
14-R42 (note #1)	W145T6
14-R52 (note #1)	W95T6
14-R82 (note #1)	W75T6
14-RF32 (note #1)	WA200T40
14-RF42 (note #1)	WA125T40
14-RF52 (note #1)	WA125T40
14-RL4 (notes #1 & 2)	(use) W145T1
14-RL7 (note #1)	W125T4
18-01	
18-02	M240T1
18-3	M225T1
18-4	M175T1
18-4X	M225T1
18-8	M145T5
18-9	M95T5
18-10	M45T5
18-52	(use) M175T1
18-82	(use) M145T5
18-F3	MA145T1

Note #1. (If resistor is necessary, use spark plug resistor connector # 0-356-150-007 (90 degree—elbow type) or 0-356-100-021 (180 degree—straight type).

Note #2. An extra gasket must be used along with the regular gasket—to make this interchange.  
 14 mm Gasket # 2-916-709-010      18 mm Gasket # 2-916-709-011

Note #3. Check piston clearance before using extended tip spark plug to replace regular electrode type.

Important! Always check electrode gap setting. Since most Bosch Spark Plugs are applicable to many different vehicles, it may be necessary to re-set the electrode gap.

